



- (1) Indicates Oxygen is "ON"
- (2) Indicates Ionization is "ON"
- (3) Indicates U.V. Lamp is "ON" (U.V. Models Only)
- (4) U.V. Switch "ON/OFF" (U.V. Models Only)
- (5) Meter indicates Dosing of Oxygen/Ionization Electrodes
NB: Do not exceed 2 on meter. If higher, reduce by turning back knob No 6, to set point 2.
- (6) Increase-Decrease Function for Power to the Oxygen-Ionization Electrodes
- (7) Ionization Program (See instructions on the faceplate)
- (8) Mains Power indicator (Blue)
 Electrode polarity indication (Red) Led's will alternate.
- (9) Oxygen :ON/OFF" switch.